

DivaStarz™

We know what's up!

Alexa™ Doll

INSTRUCTIONS

Hel-lo-oo!

I'm Alexa™! Your
personal expert on style. I
just know we're going to
be the best of friends!



Requires 4 "AA"
Alkaline Batteries
(not included).

ADULTS NOTE:

Cut the plastic
attachments and/or
thread with scissors
and discard the pieces.

Ask an adult to help

Colors and accessories
may vary.



27494-0920 G3

Keep these instructions
for future reference as
they contain important
information.

©2000 Mattel, Inc., El Segundo, CA 90245 U.S.A. All Rights Reserved.

Licensed and created by THE OBB and Robert Jeffway Jr., LLC.

Quick Start

1. INSTALL BATTERIES. Refer to page 5.

- Be sure to use only fresh 4AA alkaline batteries when replacing the batteries.
- Make sure the batteries are properly aligned (positive with + and negative with -).
- Turn the ON/OFF switch to ON.

2. SETTING THE TIME.

Doll will prompt to set the time. Doll will say "Hi, I'm Alexa™!
Time to set my clock".

a. Press the YES ("Y") button to set the clock.

b. The doll will begin to set the hour, the hours will continue to increase in the following order:

12 midnight

1 o'clock in the morning through 11 o'clock in the morning

12 noon

1 o'clock in the afternoon through 4 o'clock in the afternoon

5 o'clock at night through 11 o'clock at night

c. Press no (N) button until she arrives at the correct hour. When she arrives at the correct hour, press the YES ("Y") button. The doll will state the time with the correct hour.

(**Note:** if you do not press a button, after five seconds the doll states "Time to set the clock" and will wait for a YES ("Y") or NO ("N") button response.)

d. Once the hour is set, press NO (N) button, the doll will begin to set the minutes. The doll will state the minutes in fifteen-minute increments:

i.e.: 12:00, 12:15, 12:30, 12:45

e. Press NO (N) until she arrives at the correct time then press YES (Y). She will continue to increase the minutes until you press YES ("Y") button at the desired time. (Note: If you do not press a button, after five seconds the doll says "Time to set the clock" and will wait for a YES ("Y") or NO ("N") button response.)

Once you have successfully set the time, you and your Diva Starz™ friend are ready to play!

Note: You need to reset her internal clock. • When you replace the batteries. • When you turn the doll off. • If you make a mistake while setting the time: Turn the ON/OFF switch to OFF, then turn back to ON.


You can also set the time during play after your Diva Starz™ friend asks you a YES or NO question. Instead of replying to the question, follow the steps below to set the time:

- Gently hold down the YES ("Y") and NO ("N") buttons at the same time for 7 seconds. When your Diva Starz™ friend responds by saying, "Time to set the clock", release both buttons and repeat the steps (a – e) above.


3. DOLL WILL PROMPT PLAY WHEN YOU ATTACH FASHIONS OR ACCESSORIES TO BEGIN PLAYING.

4. TO PLAY OR CHAT WITH YOUR DIVA STARZ™:

- **To play games**, place the electronic game in her hand.
- **To hear a secret**, place the diary in her hand.
- **To hear a phone conversation**, place the cell phone in her hand.
- **To hear about her pet**, place her pet in her hand.



Buttons and Sensors



Buttons: When she asks you a “Yes” or “No” question (like: Do you like cats?), you must press the “Y” button for “Yes” or the “N” button for “No”. That way she’ll know exactly what you answered. If she asks a “Yes” or “No” question and you do not press the “Yes” or “No” button on her shoe, your Diva Starz™ friend will not “understand” your answer and may respond by asking a different question.

Sensors: Her sensors enable her to recognize her fashions and accessories. The IR (infrared) sensors enable her to recognize her friends Nikki®, Summer™ and Tia™.

Microphone: Lets your Diva Starz™ friend know when you respond to her questions. She may ask you a question like: what’s the best present you ever received? Tell her. The microphone lets her know when you’ve answered. If you don’t respond, your Diva Starz™ friend will ask two more questions. If you still do not respond, she will become silent until you are ready to play again.

Table of Contents

Here's where you can find out everything that you'll need to know about your new best friend!


Quick Start	Inside Front Cover
Buttons and Sensors	Page 1
Table of Contents.	Page 2
Diva Starz™ Doll and Accessories	Page 3
Introducing Your Diva Starz™ Friend	Page 4
Battery Installation.	Page 5
Setting the Time	Page 6
Dressing Your Diva Starz™ Friend	Page 7
Diva Starz™ Accessories	Page 8
Hair Stylin'	Page 9
Games and More!	Page 10
Playing with 2 or More Diva Starz™ Friends	Page 11
Caring for Your Diva Starz™ Friend	Page 12
Trouble Shooting Tips.	Page 12
FCC Regulations.	Inside Back Cover
Warranty	Inside Back Cover

Parents please note: We recommend you help your child insert the batteries and set the time. (See pages 5 and 6.) After that, your child should be able to play with and care for her Diva Starz™ friend on her own.


Diva Starz™ Doll and Accessories

Alexa™ really knows style!

Her diva-licious wardrobe includes: party clothes, her favorite outfits, matching accessories (of course), and even a nightgown:



BARRETTES



CELL
PHONE




HAIR BRUSH




NIGHTGOWN




DIARY




ELECTRONIC
GAME




PARTY BAG



SHIRT




TANK TOP




DRESS



DRESS



CAPRIS



KITTY

Introducing Your Diva Starz™ Friend

Hel-lo-oo!
I'm Alexa™

Hel-lo-oo Glam Girl! I'm Alexa™, your personal expert on style! I just know we're going to be the best of friends. I love sharing secrets, telling jokes, talking to my friends and I am totally into shopping. I even share my feelings and dreams with you! Ooh la la... maybe I can help you create your own personal style.



Alexa™, Nikki®, Summer™ and Tia™ are the Diva Starz™! They're **way** smart; they know each other, they move and they really respond to you. Your Diva Starz™ friend shares her feelings and even her dreams! Diva Starz™ love to share secrets, tell jokes, play games and they can always make you laugh.


Each Diva Starz™ friend comes with her own clothes and accessories that express her unique personality. She can really recognize which totally cool outfits you've put on her. Diva Starz™ also know when it's day or night and will even ask you how your day was when you come home from school!

Diva Starz™ are just like most of your other friends. Some days they don't want to wear a certain outfit or they'll tell you a new hairstyle is definitely out ...and some days they're silly and everything they say will just make you laugh.

Battery Installation

- Using a Phillips head screwdriver (not included), carefully remove the battery door located on the bottom of the shoes.
- Insert 4 “AA” batteries into the battery compartment. See the illustration (right) for proper installation. Please note: use only alkaline batteries; non-alkaline batteries will not power this toy.
- Replace the battery door and secure it with screw.
- Turn ON/OFF switch to ON.

Note: each time you change the batteries or turn the doll off, you will need to reset the time. Refer to page 6 for details.



BATTERY SAFETY INFORMATION

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Dispose of batteries safely.

Setting the Time

Doll will prompt to set the time. Doll will say "Hi, I'm Alexa™! Time to set my clock".

- a. Press the YES ("Y") button to set the clock.
- b. The doll will begin to set the hour, the hours will continue to increase in the following order:
 - 1 o'clock in the morning through 11 o'clock in the morning
 - 12 noon
 - 1 o'clock in the afternoon through 4 o'clock in the afternoon
 - 5 o'clock at night through 11 o'clock at night
 - 12 midnight
- c. Press no (N) button until she arrives at the correct hour. When she arrives at the correct hour, press the YES ("Y") button. The doll will state the time with the correct hour.
Note: *if you do not press a button, after five seconds the doll states "Time to set the clock" and will wait for a YES ("Y") or NO ("N") button response.*
- d. Once the hour is set, press NO (N) button, the doll will begin to set the minutes. The doll will state the minutes in fifteen-minute increments:
 - i.e.: 12:00, 12:15, 12:30, 12:45
- e. Press NO (N) until she arrives at the correct time then press YES (Y). She will continue to increase the minutes until you press YES ("Y") button at the desired time. (Note: If you do not press a button, after five seconds the doll says "Time to set the clock" and will wait for a YES ("Y") or NO ("N") button response.)

Once you have successfully set the time, you and your Diva Starz™ friend are ready to play!

Note: *You need to reset her internal clock. • When you replace the batteries. • When you turn the doll off. • If you make a mistake while setting the time: Turn the ON/OFF switch to OFF, then turn back to ON.*

You can also set the time during play after your Diva Starz™ friend asks you a YES or NO question. Instead of replying to the question, follow the steps below to set the time:

- Gently hold down the YES ("Y") and NO ("N") buttons at the same time for 7 seconds. When your Diva Starz™ friend responds by saying, "Time to set the clock", release both buttons and repeat the steps (a – e) above.


Doll will prompt play when you attach fashions or accessories to begin playing.

To play or chat with your Diva Starz™:

- **To play games**, place the electronic game in her hand.
- **To hear a secret**, place the diary in her hand.
- **To hear a phone conversation**, place the cell phone in her hand.
- **To hear about her pet**, place her pet in her hand.
- **To hear about parties**, place the party bag in her hand.

Dressing Your Diva Starz™ Friend

Alexa™ is totally glam and she has the cutest outfits around! If you love playing fashion designer then you and Alexa™ are going to be a fab-a-licious duo.




Each Diva Starz™ friend comes with her own special wardrobe. She's able to recognize her outfit and its color when you put it on her. To put her clothes on, just line up the clothing sensors with the sensor openings on her body. Check out the diagram (above) for an extreme close-up!

Diva Starz™ friends really know what's up, especially when you try to dress them in each other's outfits; they'll let you know that something's not right! They even know when it's time to put on a nightgown and when it's time to get dressed in the morning.

When you dress her, she may ask you to play one of her favorite fashion make over games. If you don't want to play a game right now, no problem! Press the NO ("N") button. But remember, she's your best friend and will keep on playing with you.

Flip to Games, on page 10, to find out what your Diva Starz™ friend likes to play when she's bored!

Diva Starz™ Accessories



Ooh-la-la!
There's my party bag!

Alexa™ is way into going to parties with friends, and she's all ready to go with her party bag! When you place her little kitty in her hand, she'll tell you all about her cat, Fluffy.

Your Diva Starz™ friend responds to all her accessories* when you put them in her left hand. (See illustration above.)

- When you give her the diary, she'll share her secrets with you!
- When you hear her phone ringing, give her the cell phone. She'll "chat" with her Diva Starz™ friends!
- If you feel like playing a game, place her hand-held electronic game in her left hand. She will ask you to play a game!

**Please take care of the accessories, but if you misplace a piece, you can still play by doll prompts.*

She may prompt you to hand her a specific accessory; if after several requests you do not give her the accessory, she'll go on and chat about something else. You can also place an accessory in her hand without her asking for it. If she's in the middle of talking about something else she may not get your hint. Instead, she'll do what any best friend would do, she'll just keep on talking away about whatever it is she wants to say to you at that moment! When she finishes, she will then respond to the new accessory.

Take a peek at the Games on page 10 to find out what games you can play together.

Hair Stylin'



How about
doing my hair?

*Okay, here's everything you
need to know about creating an
exciting hair-do for Alexa™.
She'll let you know if the style is
a hair-do or a hair-don't.*

Your Diva Starz™ friend comes with her own hair brush and hair barrettes. You can wait for her to prompt you to style her hair or you can come up with your own masterpiece. Always remember that when you have finished styling your Diva Starz™ friend's hair, you must tap the top of her head for her to recognize you're done (illustration left).

Gently brush her hair with her hair-brush; if you brush or pull too hard, she may respond by saying something like, "Ow!"

You may be asked to play the Hair Guessing Game; skip on over to the Games on page 10 to find out how you play.



Games and More!

Let's play a game!

The Diva Starz™ know how to have fun, and they can't wait to share their fun-a-licious games with you. Take a look at the cool games you can play together:

Minute Makeover: In this game your Diva Starz™ friend will count to 15 as you try to dress and undress her in as many different outfits as you can. Don't worry about keeping track, your Diva Starz™ friend will tell you after the 15 seconds are up! And there's no cheating; your Diva Starz™ friend knows if you put the same outfit on her more than once!

Alexa™ Says: Your Diva Starz™ friend tells you what clothes to put on her or what accessory to hand her. Listen carefully, she might trick you by not saying, "Alexa™ says".

Fashion Guessing Game: This snappy game will keep you guessing. Your Diva Starz™ friend will close her eyes and she'll think of an outfit. It's up to you to guess which outfit she picked out. Put an outfit on her. She'll tell you if you guessed right. You'll play 3 times and after that, the Diva Starz™ friend will ask if you want to play again.

Hair Guessing Game: This game is played the same way as the Fashion Guessing Game, only (you guessed it) you have to create the hairstyle your Diva Starz™ friend is thinking about. Remember that you have to tap the top of the doll's head so she can recognize when you're done.

Ask Me a Question ('kinda like Magic 8 ball®!): Your Diva Starz™ friend will make her predictions about anything; ask her a question and she'll give you a revealing answer. Diva Starz™ really know what's up!

and More!

Nicknames: Each Diva Starz™ friend loves to make up cool nicknames for you. Once she creates a nickname for you, she'll call you by that nickname; but after a while she'll decide you need a new one.

Word of the Day: Your Diva Starz™ friend will let you in on her secret word of the day! It's always something totally cool and another way for the two of you to have a lot of fun.


Diva Starz™ are **way** smart! When you get Alexa™, Nikki®, Summer™ and Tia™ together, they may surprise you and randomly talk to each other!

To increase your chances of a surprise conversation, the dolls need to face each other (it's only polite you know!). They work best when one doll's shoes are pointing toward the other doll's shoes.


- When playing with 2 dolls, have them face each other.
- To play with 3 or 4 dolls, imagine each doll is standing on the corner of an invisible square, facing in to the center.

For best results, make sure all dolls are at the same level on a smooth flat surface and facing in toward one another. The dolls should be no closer than 6" and no further away than 24". That's all it takes to get the Diva Starz™ to talk to each other.

IMPORTANT: The Diva Starz™ friends may not be able to talk to each other in direct sunlight.



WHEN PLAYING WITH 2 DOLLS, HAVE THEM FACE EACH OTHER.



TO PLAY WITH 3 OR 4 DOLLS, IMAGINE EACH DOLL IS STANDING ON THE CORNER OF AN INVISIBLE SQUARE FACING IN TO THE CENTER.

Sharing Fashions!

Diva Starz™ friends **really** know what's up, especially when you try to dress them in each other's outfits. They'll let you know that something's not OK! (Each Diva Starz™ friend has her own fave look and can distinguish her outfits from her friends'.)



Caring for Your Diva Starz™ Friend

Diva Starz™ are your new best friends, and you'll have a long lasting friendship if you remember these helpful hints:

- Never immerse your Diva Starz™ friend in water, and never wash your Diva Starz™ friend's hair.
- Do not touch her eyes or try to turn her head.
- If your Diva Starz™ friend gets dirty, wipe clean with a damp, soft cloth.
- Be sure to keep the contact sensors clean. Should they become dirty, gently wipe area with an eraser tip. Then wipe with a clean tissue or cloth. Refer to page 1 for sensor locations.
- Store all fashions and accessories in a clean dry area away from extreme heat or cold. A self-locking plastic storage bag (not included) is recommended.
- To conserve battery life, remember to turn your doll "off" if you don't play with her for a long period of time.

Trouble Shooting Tips

- If you place an outfit on your Diva Starz™ friend, or place an accessory in her hand and she does not respond:
 - Sometimes she is in the middle of a sentence or a game, and she may not immediately recognize your request. Allow her to complete the sentence, activity, or her movement (of eyelids and head). Make sure that the accessory or fashion is taken off, then snap the new fashion or accessory all the way on so she can respond to your new request.
 - If she still will not respond:
 - Be sure to keep her hand and clothing contact sensors clean. If they become dirty, gently wipe area with an eraser tip, then wipe with a clean tissue or cloth. Refer to call outs on page 1 for sensor locations.
 - If your Diva Starz™ friend's speech becomes slow or garbled, you may need to replace the batteries.
 - Be sure to use only fresh "AA" alkaline batteries when replacing the batteries.
 - Make sure the batteries are properly aligned (positive with + and negative with -).
 - Note: Each time you change the batteries or turn the doll off, you will need to reset your Diva Starz™ friend's internal clock. Refer to page 6 for details.
 - If your Diva Starz™ friend asks you to reset her clock, then continues to ask you to reset her clock, the batteries need to be replaced.
 - When playing with more than one Diva Starz™ friend, make sure all dolls are standing at the same level on a smooth flat surface and facing in toward one another. The dolls should be no closer than 6" to one another and no further away than 24".
 - If your Diva Starz™ friend should suddenly stop while playing, and the doll does not respond to any of your commands, the doll program may be 'locked up', i.e.:
 - If the doll stops moving (even after she says several sentences) she may need to be reset by switching her ON/OFF switch to OFF then back to ON.
 - Refer to page 6 to reset the clock. (You will need to reset the clock each time you turn the ON/OFF switch to OFF then back to ON.)
- Then you will be able to play with her again.
- **IMPORTANT:** The Diva Starz™ friends may not be able to talk to each other in direct sunlight.
 - Please take care of the accessories, but if you misplace a piece, you can still play by the doll prompts.

FCC Regulations

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

2 Year Limited Warranty

Mattel, Inc. warrants to the original consumer purchaser that this product will be free of defects in material or workmanship for two years (unless specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase, postage prepaid, to Consumer Adjustment Center, 15930 E. Valley Boulevard, City of Industry, California 91744 for replacement or refund at our option. This warranty does not cover damage resulting from unauthorized modification, accident, misuse, or abuse. **Valid only in U.S.A.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Send only the product to the address above. Send all correspondence to Consumer Relations, Mattel, Inc., 333 Continental Blvd., El Segundo, California 90245-5012, U.S.A. Or you may phone us toll-free at 1-800-524-TOYS, Monday - Friday, 8:00 a.m. - 6:00 p.m. Eastern Time. See telephone directory for Mattel listing.

CONSUMER INFORMATION

MATTY MATTEL™ toys



YOU CAN TELL IT'S MATTEL™! CALL us toll-free or write with any comments or questions about our products or service. Monday-Friday 8:00 a.m.-6:00 p.m. Eastern Time. Outside U.S.A., see telephone directory for Mattel listing.

Consumer Relations, Mattel, Inc.
333 Continental Blvd.
El Segundo, CA 90245 USA

1(800)524-TOYS

WE ARE DEDICATED TO QUALITY PRODUCTS.

Meet the Diva Starz™

Hi, I'm
Nikki®!

Hi, I'm
Alexa™!

Hi, I'm
Summer™!

Hi, I'm
Tia™!

We're the
Diva Starz™.
We know
what's up!

We recognize each
other, and know when
we're wearing each
other's clothes!

Diva Starz™ really talk to you and each other too.

Dolls sold separately and subject to availability.